John Deere 600 Series Flex Head

Grain Head Auger Liner Instructions


CAUTION

PLEASE REFER TO YOUR EQUIPMENT MANUFACTURER'S OPERATORS MANUAL FOR PERTINENT SAFETY PRECAUTIONS

- 1. Remove stripper plates and clean auger trough.
- 2. Starting with the center of the head, lay out panels to determine position of each piece. Ends will need to be trimmed to fit.
- 3. Install Auger Liner starting with center panel, inserting the front edge of liner under flex pan. (as shown in image 2)
- 4. Drill & Rivet at overlaps every 6-8 inches and at the front and back edges of the liner every 10-12 inches.
- 5. Re-install stripper plates over poly liner, drilling through liner and reusing existing hardware. (as shown in image 2)

NOTES:

- Liner should be installed with pressure removed from the cutterbar so that the flex pans are in forward position for installation
- Poly liner and combine header should be at 70° F or above for ease of installation and smooth fit
- Winter installations will need a warm, heated shop
- Auger can be removed for installation or the drive disconnected so it can be turned easily





120 Eastgate Drive SE Hutchinson, MN 55350

1-800-788-6483 1-320-587-2322 1-320-587-6112 (Fax)

WWW.MAYWES.COM

John Deere 600 Series Flex Head

Grain Head Auger Liner Instructions

		Panel Quantity Reference					Rivets
		Α	В	С	D	E	per Kit
20ft	82706	1	2	2	0	0	175
22ft	82707	1	2	2	1	1	200
25ft	82708	1	3	3	0	0	210
30ft	82709	1	3	3	1	1	260
35ft	82710	1	4	4	0	0	290

#42148 - Left 4ft Panel White

#42147 - Right 4ft Panel White

Ε

C

Α

В

D

#42150 - Left 2ft Panel White

#42146 - Center Panel White

#42149 - Right 2ft Panel White

(View from Operators Position looking down onto head)



120 Eastgate Drive SE Hutchinson, MN 55350

1-800-788-6483 1-320-587-2322 1-320-587-6112 (Fax)

WWW.MAYWES.COM