

The Original Farmer Designed 59711 U.S. Hwy 12, Litchfield, MN 55355 1-888-485-8411

Assembly Instructions AGCO 3000 30" Center (3016)



- Picture #1
- Picture #2











- 1. Remove filler plate between the row units and replace with GVL rear hold-down bracket (Item #8) using (4) 5/16" x 3/4" carriage bolts and nuts. (Center and Tighten) (Picture #1)
- 2. Install the front hinge bracket (Item #9) to the front of the GVL main frame (Item #3) using 3/8" x 1" carriage bolts and nuts provides. (Leave Loose)
- 3. Install the hooks (Item #13) on the front hinge bracket using 3/8" x 1" carriage bolts and nut provided. (Leave Loose) (Picture #2)
- 4. Bolt Hinging Bracket Mounting Angle (Item #10) in the 1/2" holes that are normally used to hold the original hinge bracket. (Use 2 hole side of bracket) Note: May have to grind small upper lip on Row Unit. (Picture #3)
- 5. Bolt Front Hinging Bracket Mounting Plate (Item #11) to Mounting Angle (Item #10). (Use front 2 holes) using 1/2" x 1" carriage bolts and flange nuts. (Center and align plate between row units and tighten bolts. (Picture #3 & #4)
- 6. Bolt Lower Hinging Bracket (Item#12) to the Front Hinging Bracket Mounting Plate (Item #11) using 1/2" x 1" carriage bolts and flange nuts. (Leave Loose) (Picture #5)
- 7. Set the **GVL** Gatherer Shields in place inserting the hook end first. (Picture #6) Next tilt the back down through the rear hold-down pins. (Item #34) The pins are tapered to self align. (Picture #7)
- 8. Position the Gatherer Shield and tighten the bolts.
- 9. Adjust the rear hold-down pins up or down so the lynch pins (Item #15) are snug (The 5/8" washers are for under the lynch pins), then tighten hold-down pin nuts. (Picture #7)
- 10. The PVC pipe around the adjustment chain. (Must be removed.) (For shipping only)

